


Bonfino

AirLuxe Cabin Stroller

Age Group

0+
MONTHS



Style Code

BF0BGST008

Note: Please take a few minutes to read this manual. This will help you assemble and use the stroller suitably. Keep this manual for future reference.

Warning!

To ensure baby's safety always use the seat belt. Place it between the baby's legs.

To ensure baby's safety apply the brakes when the stroller is stationary to prevent sliding and potential danger.

For your child's safety

- This product is suitable for one child at a time
- This product is suitable for children who cannot sit unaided, roll over and cannot push themselves up on their hands and knees
- Never leave the child unattended in the stroller
- Do not let other children play with the product
- Never use the stroller on stairs or escalators. Be careful while going up or down the slope
- Any load on the push bar and or at the back of the backrest of the stroller will affect the balance
- Do not place things more than 3kg in the storage basket
- Do not hang purse, shopping bag, parcel or accessories on the handle
- Wheels should be locked before placing and removing the children
- Ensure all the locking devices are correctly engaged before use
- Sitting position is not suitable for children below 6 months
- Always use the safety harness
- Not advised to use on very rough terrains
- This stroller is not suitable for running and skating
- Make sure the children are at a safe distance while unfolding and folding the stroller
- Please check the stroller for any loose parts, damaged or broken parts before each use
- Replace at the first signs of damage

Cleaning and Maintenance

Cloth Cleaning

1. It is recommended to use a damp cloth for dust and general stains.
2. Use mild lotion.
3. Seat cover and canopy cover are not machine washable.
4. Leave the washed cloth cover in a ventilated place and dry it. Do not expose it to direct sunlight.
5. Do not brush the cloth cover hard as it may cause damage to the fabric.

Frame Cleaning


1. Do not use a corrosive lotion to scrub the frame.
2. Use a wet cloth and mild lotion to wash the frame.

Before assembly, please double check all parts as shown are included in the package. For any missing or defective parts, or sharp edges, please contact customer service immediately. To guarantee the service life of the stroller, please use it correctly under the instructions and make it through inspection regularly. Never use it if any parts are missing or broken.


Parts & Accessories




- | | |
|----------------------|---------------------------|
| ① Handle bar | ⑦ Five-point safety belts |
| ② Canopy | ⑧ Folding button |
| ③ Removable bumper | ⑨ Front wheel |
| ④ Shopping basket | ⑩ Rear wheel |
| ⑤ Directional button | ⑪ Cross belt |
| ⑥ Leg-rest | ⑫ Brake |




Unbox the stroller, hold the handlebar, and push upward to engage the folded joint. When you hear a "click," the stroller is now open.




Push the rear wheel to the end in the direction shown (J) to complete the installation. To disassemble, pull down with the right hand (K1) and use the left hand to remove the wheel in the direction indicated (K2). Wheel disassembly is complete.




Insert the bearing until you hear a "click," then install the front wheel. Press (C) to detach the wheel. Pull down the directional button (D) for straight movement; pull up to release and return to universal.






Press down in the direction of (N) to brake. Lift up in the direction of (M) to release the brake.




Seat Reclining- Hold the button and straighten the belt while adjusting up and down to achieve the baby's comfortable angle.

WARNING:

For the safety of the baby, when the stroller does not move, the wheels must be braked to avoid the danger of sliding.




For leg-rest adjustment, press buttons (G) and (K) when lowering it. When raising the leg rest, adjust directly, and you will hear a "click."




Adjust the canopy by moving it forward in the direction of the arrow on the safety devices.

→ Squarelock ←




Insert the safety buckle into the insurance outlet; a "click" sound indicates it is locked.

← Open →



To open the safety belts, press the safety buckle inward and pull up.





Ensure wheel assembly and stroller safety devices are locked before use. Place baby's arms into left and right seatbelt, insert both sides into straddling safety button, ensuring they cannot be pulled off. Adjust the safety belt length as shown in the picture.

WARNING:

For the safety of the baby, please use the safety belts at any time. Please put the cross belt between the legs of the baby.



Hold the handlebar, pull in the (D) direction with the thumb, and press the double lock button up (E) with the other four fingers to automatically fold the stroller.



Stroller folding is complete.

Bonfino

Imported & Marketed by:

Digital Age Retail Private Limited

Rajashree Business Park, Plot No. 114, Survey No. 338, Tadiwala Rd.,
Near Sohrab Hall, Pune 411001 Maharashtra, India

For Any Feedback, Contact

Customer Care Executive No.: +91-135-3501241 or

E-mail: customercare@darp.in

Customer Care Address: Same as Marketer's address

MADE IN CHINA